

Dispersal equipment In-duct spray systems



Jetstream 100

Product Profile

The Jetstream 100 can power up to four auto-clean, air-misting nozzles, allowing it to effectively neutralise odour in an extraction or ductwork system, or in localised external applications. The Jetstream 100 is simple to operate, with a manual on/off switch, and is supplied with brackets for wall mounting.

An intrinsically safe, ATEX compliant odour control system, the Jetstream 100 is a compact, low-cost misting unit, which runs on compressed air. The Jetstream 100 is ideal for small applications, where space is limited or where a low-cost solution is needed. Because it runs on compressed air rather than electricity, there is no risk of the Jetstream 100 producing a spark, which makes it 'intrinsically safe' and ideal for use where volatile materials are present, such as in oil refineries and petro-chemical manufacturing & processing plants.

How it Works

The Jetstream 100 produces a compressed air stream and when used in conjunction with Air Spectrum's odour neutraliser *Odr*, produces a very fine mist that is sprayed into the extract ductwork or stack. The mist interacts with the odour particles and neutralises them. For more details about how *Odr* works, please visit our website.

Key Applications

- Petro-chemical processing plants
- Food and drinks manufacturing
- Commercial kitchens
- Restaurants
- Take-away food outlets
- Localised external applications

For more information contact:

E: Enquiry@AirSpectrum.com
T: +44(0)1905 362100
F: +44(0)1905 362101



The Jetstream 100 typically uses auto clean nozzles to minimise maintenance needed (they are less prone to blocking) and to produce finer atomisation, which provides superior coverage.

Features

- Intrinsically safe, ATEX compliant
- Simple to use
- Runs on compressed air (*customer supplied*)
- No electricity required
- Compact size
- Low cost
- Auto clean nozzles provide long-life, extra fine atomisation
- Wall mounting brackets included
- Manual on/off operation
- Two regulators and pressure gauges
- Runs up to 4 auto clean nozzles

Air Spectrum Environmental Limited continually strives to improve its products and therefore reserves the right to introduce modifications to their product range without notice.

www.AirSpectrum.com