

# Dispersal equipment In-duct spray systems



## Jetstream 200

### Product Profile

The Jetstream 200 is a compressed air misting system, driving multiple nozzles to effectively suppress odour in extraction or ductwork systems, for use in misting scrubbers, or in localised external applications. Featuring a 7-day timer, it can also be supplied with pulse control and remote control response facility which can be triggered from an external remote source, such as a windswitch. The Jetstream 200 requires a compressed air and mains electricity supply.

### How it works

The Jetstream 200 produces a compressed air stream and when used in conjunction with Air Spectrum's odour neutraliser *Odr*, produces a very fine mist that is sprayed into the extract ductwork or stack. The mist interacts with the odour particles and neutralises them. For more details about how *Odr* works, please visit our website.

### Key Applications

- Food and drinks processing
- Commercial kitchens
- Localised external applications
- General manufacturing



The Jetstream 200 typically uses auto clean nozzles to minimise maintenance needed (they are less prone to blocking) and to produce finer atomisation, which provides superior coverage.



### Features

- Low liquid level indicators
- 7 day timer or remote signal system (optional windswitch)
- IP65 rated enclosure for electrics
- Auto clean nozzles
- User adjustable dosing levels
- CE marked

### Key Information

<b>Water consumption:</b>	4-8 bar potable water required (Flow = 10 litre per min)
<b>Electrical supply:</b>	110/240V – 16 amp single phase
<b>Compressed air supply:</b>	4-10 bar dry compressed air required
<b>Flow rate per nozzle:</b>	1.2m <sup>3</sup> per hour

### For more information contact:

E: [Enquiry@AirSpectrum.com](mailto:Enquiry@AirSpectrum.com)  
T: +44(0)1905 362100  
F: +44(0)1905 362101

Air Spectrum Environmental Limited continually strives to improve its products and therefore reserves the right to introduce modifications to their product range without notice.

# [www.AirSpectrum.com](http://www.AirSpectrum.com)