

Dispersal equipment Fans & Atomisers



Vortex Fan

Product Aim

The Vortex Fan system is specifically intended to provide focused control of acute odour release within localised environments. Its purpose is to neutralise odour as it is being generated or at source. Regulatory compliance is then ensured and the likelihood of complaints is limited.

How it Works

The Vortex Fan can be wall mounted or sited on an optional floor stand, allowing it to be positioned adjacent to the offending area. Liquid neutraliser and water is pumped through the fan which produces a fine mist of micron fine particles that can be propelled up to 10 metres, rapidly and effectively reducing odour. With a 300-degree rotation feature and a variable flow control, the system provides maximum coverage and flexibility. Its exclusive nozzle-free design eliminates both plugging problems and the need for filtering systems, thereby reducing running and maintenance costs.

The Vortex Fan's ability to generate such a small droplet diameter is critical to achieving optimum *Odr* delivery. The unit can be supplied with an optional dosing pump which means that the potential for wastage through over-application is prevented. The system works most efficiently with the *Odr* additive range, non-toxic odour neutralisers supplied by Air Spectrum, which are effective in any environment. Please see the *Odr* product datasheet or website for more information.



Features

- 300 degree rotation function
- Wall or optional stand mounted
- Variable flow control

Key Information

- Mains electricity powered (240V)

For more information contact: E:
Enquiry@AirSpectrum.com
T: +44(0)1905 362100
F: +44(0)1905 362101

Air Spectrum Environmental Limited continually strives to improve its products and therefore reserves the right to introduce modifications to their product range without notice.

www.AirSpectrum.com